



HELPFUL HINT:  
 WEDGE BEHIND BEVELED BLOCK CAN  
 BE A GOOD PLACE TO RUN ELECTRICAL  
 WIRES AFTER SCREWS ARE IN PLACE.



**BEVELED BLOCK 2x WALL/ROOF**  
**PREMIER BUILDING SYSTEMS**